


FIG. 4B







FIG. 4D





<u>420</u>

421~	INCOMING MAIL REPORTED	0
422~	RECEPTION FAILURE	×

FIG. 5




FIG. 6A




FIG. 6B 6-1 6-2 (S623 (S626 ςS617 CREATE NEW MAIL MESSAGE **CREATE NEW** CREATE NEW MAIL MESSAGE MAIL MESSAGE **DESTINATION:** SUBJECT: TEXT: TEXT:
→SEND SUBJECT: SEND →TEXT: **→SAVE** (S618 (S624 (S627 PRESS "SET" KEY PRESS "SET" KEY PRESS "SET" KEY (S619 (S625 s628 **ENTER TEXT START DISPLAY LIST OF TRANSMISSION OUTGOING MAIL ENTER USING DIALING BUTTONS** <sub>5</sub>S620 **EXIT SET TEXT TABLE** (S621 ENTER CHARACTERS (KANA) (S622 PRESS "SET" KEY

FIG. 7





FIG. 8A






FIG. 9




FIG. 10





FIG. 11








FIG. 13








FIG. 16




FIG. 16

